

Incoming calls are rejected by "403 Use Proxy"

Problem

Snom phones just accept by default calls which are send from the same IP as configured as Outbound proxy or Registrar in the identities. Calls and messages from other IPs are rejected with "**403 Use Proxy**". The Phone Log will also print an error similar to this when a SIP request from a not-trusted address:

```
Apr 10 21:47:32.138 [DEBUG1] SIP: recv INVITE (1: 1-5324@10.110.12.106) <- Udp:10.110.12.106:5060 <-----  
this message is displayed only with log level DEBUG1  
Apr 10 21:47:32.140 [ERROR ] SIP: reject Request, not trusted address (0, Udp:10.110.12.106 )
```

- The only exception is if the received **SIP method** is an **ACK** for an existing call, in which case the phone does not reject it, but it still prints the error "**SIP: reject Request, not trusted address**" in the log.
- This mechanism should protect against **spam via SIP** or **unauthorized calls**. In some environments though, the calling proxy is not the same as the outbound-proxy used by the phone for outgoing calls, for this reason it is possible to change the phone configuration to accept methods from untrusted IPs.

Solution

- With a high chance the calls are received from a server different to the outbound-proxy.
- The setting **filter_registrar** has to be set to "off".



Attention: The phone will afterwards accept calls from any source - also calls from unauthorized sources.



Further Information

- [VoIP Essentials](#)
- [Visit the Snom Forum](#)
- [Open a support ticket](#)
- [Find a local partner](#)

Related articles

- [Entering Snom Deskphone Web Interface - WUI](#)
- [Get the snom phone ready for operation](#)
- [How can I backup and restore the phone configuration](#)
- [How can I configure a second hand Snom device that still points to the old PBX because of a redirection](#)
- [How can I obtain a SIP trace from the phone](#)
- [How to - Core Dump](#)
- [How to capture large or permanent PCAP traces](#)
- [How to obtain a log from a desktop phone](#)
- [How to obtain a SIP trace from a deskphone](#)
- [How to setup a Syslog server on a Desktop phone](#)
- [How to store a PCAP trace into an USB mass-storage device](#)
- [How to store a phone syslog into an USB mass-storage device](#)
- [How to store a SIP trace into an USB mass-storage device](#)
- [Incoming calls are rejected by "403 Use Proxy"](#)
- [Is my Snom phone still covered by warranty](#)
- [My phone displays the SIP Disabled - error, how can I fix it](#)
- [Reboot your Snom Phone](#)
- [Setting up a Snom Deskphone](#)

- [Setting up WLAN Connection on Snom Deskphone](#)
- [Store HTTP-Trace on USB Stick](#)
- [Store Pcap on USB Stick](#)
- [Store SIP-Trace on USB Stick](#)
- [Store Syslog on USB Stick](#)
- [Troubleshooting How-to](#)
- [What kind of DTMF types Snom phones support and how to change them](#)
- [Why does my Snom phone always end the current call after a certain time](#)