

M700



Hardware Specifications

Characteristics	Value
Product name	M700
Part no.	00003928 (EU) 00003929 (US)
General Features	
Dimensions	211 x 150 x 58 mm (HxLxW)
Cell type	Multi-cell, up to 254 base stations per set-up
Number of connected handsets	30 per base station, up to 1000 in multi-cell set-up
Number of simultaneous calls	8 NB, 4 WB calls per base
Compatible handsets	M25, M65, M70, M80, M85, M90
Repeater support	yes
GAP support	no
Power over Ethernet class (PoE)	Class 2
Homologation	
Type approval	CE mark, Electrical Safety EN60950

 [DECT Multi Cell Installation](#)

How Tos

- [Configuring multiple SIP Extensions with an M-series DECT handset](#)
- [DECT - 1. Multicell Deployment Guide](#)
- [DECT - 2. Physical installation](#)
- [DECT - 3.0 Multicell setup](#)
- [DECT - 3.1 Add Extensions](#)
- [DECT - 4. Site Survey](#)
- [DECT - 5. Measuring with DECT Discovery Mode](#)
- [DECT - 6. Best Practises](#)
- [DECT - M700 - Activate Multicell Mode](#)
- [DECT Multi Cell Installation](#)
- [DECT Solution How-to](#)
- [How can I register the A190 headset on an M-Series base station](#)
- [How can I register, deregister the A150 and the C52-SP on the A230 DECT Dongle](#)

FAQ

- [Adding M5 repeaters in a multicell environment](#)
- [After upgrading my DECT base to 400B02 my M65 cannot register anymore](#)
- [After upgrading the base to version 400B02 the provisioning via HTTPS/TLS isn't working anymore](#)
- [Assign a handset to a SIP account on a M300](#)
- [Attended or blind call transfer of the 2nd call results in merging the 1st and 2nd incoming call](#)
- [Can I daisy-chain M5 DECT repeaters](#)
- [Can I register a 3rd party DECT handset or repeater to a Snom M300, M700, M900 base station](#)
- [Do the M300, M700, M900 support GAP](#)
- [Dropped connections and failed handset handovers in a DECT multi-cell](#)
- [How can I trigger a settings sync on a DECT M300, M700, M900](#)

Documentation

- [Declaration of Conformity > DoC_M5_M25_M65_M300_M700_Q3_2017.pdf](#)
- [User Manuals > M700_M300_Admin_Guide_de.pdf](#)
- [User Manuals > M700_M300_Admin_Guide_en.pdf](#)
- [User Manuals > M700_Multicell_Deployment_Guide.pdf](#)
- [User Manuals > Provisioning_Guide_M900_M700_M300.pdf](#)
- [Quick Installation Guides > QIG_M700_en.pdf](#)
- [Datasheets > snom_M700_datasheet_de_2-0-0.pdf](#)
- [Datasheets > snom_M700_datasheet_en_2-0-0.pdf](#)
- [Datasheets > snom_M700_datasheet_es_2-0-0.pdf](#)
- [Datasheets > snom_M700_datasheet_fr_2-0-0.pdf](#)

- How can I register,deregister the A150 on the A230 DECT Dongle
- How can I register,deregister the C52-SP on the A230 DECT Dongle
- How to factory reset an M15 SC handset
- How to get a Log from the DECT base
- How to get a SIP trace from the DECT base
- How to use the pound key to debug in-a-call issues
- Is it possible to assign more than one DECT handsets to an identity
- Datasheets > snom_M700_datasheet_it_2-0-0.pdf
- Datasheets > snom_M700_datasheet_ru_2-0-0.pdf
- Datasheets > snom_M700_datasheet_tr_2-0-0.pdf