

goto_monitor_state_on_line_activity

Web User Interface

V8: Advanced - Behavior(Tab) - Phone Behavior (Section) -> Go to Call-Monitor on Activity

Phone User Interface

N/A

Firmware

XML Configuration

```
<goto_monitor_state_on_line_activity perm="PERMISSIONFLAGS">VALIDVALUE</goto_monitor_state_on_line_activity>
```

Description

When any of your monitored lines shows an activity (other than idle), the phone will automatically display the call-monitor state. This behaviour is similar to the setting Call Pickup and replaced it since version 8.7.2 on all phones models.

See also `pui_states_allowing_state_switch_on_activity` and `goto_virtual_keys_state_on_activity`.

Valid Values

on
off

Default Value

off